


GX™-II QUICK REFERENCE CARD

BASIC OPERATION

- Press POWER to acquire a target.
- Press and hold MODE for at least 1 second to enter the Quick Set Menu.
- Once you have entered the Quick Set Menu, press and release MODE to navigate through the menu options.
- Press POWER to toggle Quick Set Menu options on/off.
- To reset factory settings, press and hold POWER and MODE simultaneously for at least 10 seconds.



TRUE GOLF RANGE

- True Golf Range (TGR) provides accurate ranging information matched to the slope of the shot and current conditions to compensate for uphill shots that play long and downhill shots that play short.
- To Activate TGR:
 - Press POWER to activate the rangefinder.
 - Press and hold MODE for at least 1 second to enter the Quick Set Menu.
 - While the TGR icon is flashing, press and release POWER as necessary until the TGR icon is displayed steadily and the word "ON" is shown in the bottom of the display.
 - To save current settings let the rangefinder automatically power-down (20 seconds) or simply press and hold MODE for at least 1 second.

SETTING THE CURRENT TEMPERATURE AND ALTITUDE

- Temperature and altitude are some of the factors used to determine TGR ranges; inputting the current conditions will increase the accuracy of your TGR measurement. TGR must be activated to input the current conditions.
- To input the current conditions:
 - Activate TGR.
 - Press MODE; the temperature icon and last saved temperature will be flashing.

CURRENT TEMPERATURE AND ALTITUDE (CONTINUED)

- Pressing and releasing POWER will increase the current temperature setting by 5 degrees; press MODE to save the appropriate setting and move to the current altitude input.
- Pressing and releasing POWER will increase the current altitude by 500 feet.
- To save current settings let the rangefinder automatically power-down (20 seconds) or simply press and hold MODE for at least 1 second.

CLUB SELECTOR

- When activated, the Club Selector recommends the proper iron for the current distance, shot angle, environmental conditions, and multiple other factors.
- TGR must be activated to use the Club Selector
- To activate the Club Selector:
 - Activate TGR.
 - Input current temperature and altitude; then press MODE.
 - While the Club Selector icon is flashing, press and release POWER until the icon is displayed steadily and the word "ON" is shown in the bottom display.
 - To save current settings let the rangefinder automatically power-down (20 seconds) or simply press and hold MODE for at least 1 second.
- Specific striking distances for your 8-iron, 6-iron, and 4-iron must be input prior to initial use.
- To input specific striking distances:
 - Activate the Club Selector and press MODE.
 - The last saved distance for an 8-iron shot will be displayed; press and release POWER until the appropriate distance is displayed; then press MODE.
 - Follow the same procedure for your 6-iron and 4-iron striking distances.
 - You will be asked to input the proper temperature and altitude at which each distance was obtained. Follow the same procedure using POWER to change the setting and MODE to advance to the next step. Accurately entering this information will tell your GX-II how to properly adjust for current conditions.
 - To save current settings let the rangefinder automatically power-down (20 seconds) or simply press and hold MODE for at least 1 second.